```
1
     `timescale 1ns / 1ns // `timescale time unit/time precision
 2
 3
    // 7 to 1 multiplexer
4
    module mux7to1(input [9:0] SW, output [9:0] LEDR);
5
        wire [6:0] data;
 6
        wire [2:0] sel;
7
8
         // Input assignment
9
         assign data = SW[6:0];
10
         assign sel = SW[9:7];
11
12
         // Multiplexer code to select data
13
        reg out;
14
         always @(*)
15
        begin
16
             case(sel[2:0])
17
                 3'b000: out = data[0];
18
                 3'b001: out = data[1];
19
                 3'b010: out = data[2];
20
                 3'b011: out = data[3];
21
                 3'b100: out = data[4];
22
                 3'b101: out = data[5];
23
                 3'b110: out = data[6];
24
                 default:;
25
             endcase
26
         end
27
28
         // Output
29
         assign LEDR[0] = out;
30
   endmodule
```